

II,I UV POOLS

## **UV System**

A UV Sanitization System is a very handy piece of equipment.

Not only does it sanitize your pool water, but it also allows you to use less chemicals to keep the water in balance therefore saving you time and money.





## **UV System Tips**

- Your UV system has two lamps that need to be replaced every 2 years on outdoor pools in Winnipeg. On indoor pools the lamps should be replaced every year.
- The UV lamps become ineffective after 2 seasons of use. You will notice chlorine demand rising as well as the lamps become ineffective.
- The quartz tube that houses the UV lamps should be cleaned when the lamps are replaced.



## Summarizing

- Connect the 2 plumbing unions (water pipes) and be certain the rubber o-rings are in place.
- Plug in your UV system to a gfi protected receptacle (plug)
- Once your pool pump is running, your UV lamps should turn on, and the clear indicator ring on the body of your UV system should glow a bluish-purple colour.



## Winterizing

- Disconnect the two plumbing union nuts. Tip unit on its side to drain all the residual water out.
- Take note of the two black rubber o-rings on the unions and store those with the UV unit.
- Store in a heated area for the winter, such as your basement.

