




Safety Cover Care Guide



UV POOLS

Water Level

The water level in the pool should always be kept within 16" or less of the top of the pool deck.



Water Treatment

Be sure your pool has the proper level of sanitizer (chlorine) and algaecide before shutting down your pool pump for the winter. This will insure that the water is clear upon opening in the spring. If the cover is left on when the temperature has gone beyond 15°C, it may be necessary to add algaecide to maintain water clarity.



Removal and Storage

The cover may be hosed off and should be allowed to dry before fan folding for storage in the supplied mesh bag.



Anchors

After removing or prior to installing the cover, clean out all the brass anchor sockets with a stream of water. This bi-annual cleaning will assure proper anchor function. When your cover is not in use, screw the anchors down completely to keep out debris and prevent tripping and foot injuries.



Cover Tension

The tension of your cover once installed is important. The tension may need to be adjusted over time, however, we properly tension it when we install the brass anchors.

The tension is measured by the pre-load on the springs. You can measure this by comparing the spring in the relaxed state vs when the cover is installed (spring is pre-load compressed). This difference in pre-loading of the springs should not exceed 1".



Cover Tension

If your cover is tensioned too tight, the straps and springs can get damaged. If the cover tension is too loose, then your cover will flap in the wind which will cause the cover to rub on the coping and concrete causing wear pre-maturely.

